



Toshiba Satellite L45-S7423 LCD Display Replacement

This guide demonstrates to the user how to remove and install the LCD display for the Toshiba Satellite L45-S7423.

Written By: Stephen Sippel



INTRODUCTION


The LCD display can be easily separated from the laptop body to allow for replacement if it is damaged or functioning improperly.



TOOLS:


- [Phillips #00 Screwdriver](#) (1)
 - [Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery



- Make sure the battery lock switch is switched to the unlocked position.
- The battery is unlocked when the battery lock switch is slid to the side with an image of an unlocked lock.

Step 2






- Slide the battery release switch to the left.
- ⓘ The switch is spring loaded, so you must hold the switch in place while removing the battery.

Step 3



- Using a finger, lift up the battery.
- ☑ The battery release switch must be held in place.

Step 4 — Bottom Access Panel




- Remove the 5 Phillips screws holding the panel in place.
- ⓘ These screws are permanently fastened to the panel; they are designed to be removed only partially to avoid loss.

Step 5



- Use a finger to remove the panel by lifting up on the provided removal tab.


Step 6 — LCD Display



- Remove the Phillips screw holding the panel in place and then use a finger to remove the panel.


i This screw is not designed to be completely removed, it is permanently fastened to the panel to avoid loss.

Step 7



- With the aid of a plastic removal, disconnect the two wires attached to the wireless card.

Step 8




- Remove the yellow tape holding the black and the white wires in place.

Step 9



- Unwind the wires from the plastic tabs holding the wires in place.

Step 10



- Remove the screw holding the ground cable in place.
 - One 4.5 mm Phillips screw.

Step 11




- Disconnect the video cable connecting the display to the base of the laptop.

Step 12



- Pop off the laptop's hinge covers using a spudger tool.


 Only a small amount of force is required. Excessive force may permanently damage the hinge covers.

Step 13



- Remove the two screws on the back side of the laptop holding the LCD display in place.
 - Two 8.5 mm Phillips screws.

Step 14




- Remove the final two screws on the bottom side of the laptop holding the LCD display in place.
 - Two 8.5 mm Phillips screws.

Step 15



- Carefully pull apart the LCD display from the base by pulling vertically upwards on the display.

 Be careful as you remove the display not to pull too hard on the cables as they pass through the opening.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 07:57:09 PM.